

Self inflating system for occupied ducts

Mounting instruction

Version 2019-12

INSTALLING:

1. Clean the interior of the conduit and the cable with a cloth



2. Remove the wrapping and unroll



3. Open the bag OKT and remove the adhesive internal protection film



4. Apply lubricant on both OKT bag sides and on cable sheath



5. Roll up the OKT around the cable, overlapping the two adhesive sides and leveling it inside the conduit



6. Pull the ribbon upwards to inflate the OKT



UNINSTALLING:

Pierce OKT bag, separate cables and extract it with mechanical clamp, turning it on itself

