





- Rotation sensitive
- Glass interface(white & black)
- Compatible with all universal series RF receivers

- Control 1 zone/area

Picture		Brief introduction of buttons
		 <p>Click the knob to switch ON/OFF. Rotate the knob to dim between 1% to 100%.</p>
Operation Voltage	Operation Frequency	<p><b>Note : This remote controls 1 zone (area) receivers, the zone can pair with countless receivers. 1 receiver can be paired by max 8 different remote controls.</b></p>
3V(CR2032)	868MHz	
Size		
		

## Installation



**Protective film**  
Before the first use, please remove it

## Operation

**Note:Before the first use, please remove the protective film on the battery.**

- Pair with RF receivers:**

Click "Learning Key" on RF receiver

→

Rotate or click the knob, led lights flicker twice means well paired
- How to delete the pairing:**

Power on the RF receiver, hold the "Learning Key" over 3 seconds until connected led lights flicker twice means well deleted.