

F Installation

GB Installation

D Installation

I Installazione

E Instalación







P instalação

NL installatie


FIN Asennus

SE Installation

N Installasjon



- F** Limitation **GB** Limitation **D** Begrenzung **I** Limitazione **E** Limitación
P Limitação **NL** Begrenzing **FIN** Kalibrointi **SE** Begränsning **N** Begrensning



- F** Calibration **GB** Calibration **D** Kalibrierung **I** Calibrazione **E** Calibración
P Calibração **NL** Calibratie **FIN** Säädön Rajoitus **SE** Kalibrering **N** Kalibrering

