

# AVK TENSILE SOCKET JOINTS FOR PE PIPES

Mounting instruction / Montagevejledning  
Einbauanleitung / Instruction de montage

**OPTION 1**

1A.

PE	✓
PVC	✗
DI	✗
STEEL	✗

2A.

90°

3A.

20° - 30°

**OPTION 2**

1B.

+	✗	*
PE	✓	
PVC	✗	
DI	✗	
STEEL	✗	

2B.

90°

3B.

4.

A\*\*

LUBE

5.

LUBE

6.

X < 5 mm

\* 05-025-54002  
05-032-54002  
05-040-54002  
05-050-54002  
05-063-54002

**! Only available in SDR 11**


**A**

\*\* DN 25 - Ø32 mm = 66 mm  
DN 32 - Ø40 mm = 75 mm  
DN 40 - Ø50 mm = 91 mm  
DN 50 - Ø63 mm = 111 mm

## Mounting instruction

Montagevejledning / Einbauanleitung /  
Instruction de montage

AVK Tensile socket joints for PE pipes



9632500129\_rev AC

[www.avkvalves.eu](http://www.avkvalves.eu)

