


Accessories and integration

Fully equipped, perfectly modular



SN201-IH	=	coupling interface / auxiliary contact
SN201-S	=	signal contact
S2C-H6R	=	auxiliary contact
S2C-S/H6R	=	signal/ auxiliary contact
S2C-S/H6R (H)	=	signal/ auxiliary contact used as auxiliary contact
F2C-A	=	shunt trip
S2C-UA	=	undervoltage release
S2C-OR	=	overvoltage release

① The interface has to be installed in order to accessorize DS203NC with the System pro M compact® series accessories.