






MOUNTING INSTRUCTIONS FOR PVM and PVP 16-32A
ASENNUSOHJE PVM and PVP 16-32A
MONTERINGSANVISNING FÖR PVM and PVP 16-32A
Инструкция по установке выключателей PVM and PVP 16-32A

<p>①</p> 	<p>③</p> <p>Pz2/1x5 Attention: Please ensure 1,8Nm - 2,0Nm</p>  <p>NOTE: IP66 (IEC 60529) When used IP66 or better cable entries</p> <p>(1.5-16)mm² Cu</p>
<p>②</p> 	<p>④</p>  <p>OFF O</p> <p>⑤</p>  <p>PZ2/1x5-7 2,0 Nm MAX</p> <p>1x5 PZ2</p> <p>Defeat mechanism Ohitusmekanismi Förbi koppling Защитный механизм</p>

