



# PISTOLIITTIMIEN ASENNUSOHJE PE-PUTKILLE

**OPTION 1**

1A.

PE	✓
PVC	✗
DI	✗
STEEL	✗

2A.

90°

3A.

20° - 30°

**OPTION 2**

1B.

PE	✓
PVC	✗
DI	✗
STEEL	✗

2B.

90°

3B.

4.

A\*\*

LUBE

5.

LUBE

6.

X < 5 mm

\* 05-025-54002  
 05-032-54002  
 05-040-54002  
 05-050-54002  
 05-063-54002

**! Tukiholkki SDR11 putkelle**


**A**

** DN 25 - Ø32 mm	=	66 mm
DN 32 - Ø40 mm	=	75 mm
DN 40 - Ø50 mm	=	91 mm
DN 50 - Ø63 mm	=	111 mm

# Asennusohjeet



9632500129\_rev AB-Fin



[www.avkfinland.fi](http://www.avkfinland.fi)