


















0041827, 0040827
0041822, 0040822








- ✓ 0041827, 0040827, 0041822, 0040822
- ✗ 0041812, 0040812



11 b



12 b



LED INDICATION		STATUS		DESCRIPTION
LED Colour	Status	Flashing		
		ON	OFF	
Green	●			Battery Connected and Charging
	☼	0.25 sec	0.25 sec	Functional Test in Progress
	☼	1 sec	1 sec	Duration Test in Progress
Red	●			Lamp Fault
	☼	0.25 sec	0.25 sec	Battery Fault
	☼	1 sec	1 sec	Battery Needs Replacement
	☼	1 sec	3 sec	Battery Temperature Error Temperature above 60±2°C or below 0+2° C
Red/Green	●			Emergency Mode

