

EN | Vieser Line Maintenance Guide



How to clean Vieser Line

1. Lift the Vieser Line grating out of the frame by using the lifting tool.
2. Clean excess dirt from the frame.
3. Remove the drain trap from the floor drain by lifting the blue handle.
4. If the drain trap in the drain does not have a handle, take hold of the lower part of the drain trap. Bend the lower edge slightly towards the outlet pipe and lift the drain trap out in a tilted position.
5. If the drain trap has not been removed for a long time, it may be tight.
6. The flow regulator of the side inlets in the trap can also be removed for cleaning.
7. Clean the drain trap and floor drain thoroughly and rinse.

After cleaning

8. Check that the drain trap's grey lip seal is in place and moisten it with soapy water, for example.
9. Install the drain trap back into the floor drain and check that it is properly in place. Be sure to also reinstall the flow regulator in the trap.
10. Press the Vieser Line grating back into place.

The drain may emit an unpleasant odour

- If the drain trap is not properly in place.
- If the drain trap seal is damaged.
- If the drain is dirty.

Cleaning the Vieser Line grating

- Clean the Vieser Line grating on both sides and remove accumulated dirt.
- Clean any stubborn dirt from stainless steel grating by rubbing it gently.
- Calcium buildup is easiest to remove gently with an acidic cleaning agent.

The floor drain should be cleaned if the water flow slows down or the drain begins to smell. **We recommend cleaning at least once a year.**

The grating of the Vieser Line floor drain can be replaced. The different grating options can be found at: www.vieser.fi.

A special drain trap is available as a spare part for the Vieser Line floor drain. The special trap is advisable if the drain is only used seldom or temporarily. The Vieser One and Vieser special drain traps prevent the drain from drying out and eliminate any smells.